

SERVOREELER SYSTEMS

XEDIT Corporation


218-31 Ninety Seventh Avenue

Queens Village, New York 11429

Web site: www.servoreelers.com

e-mail: srsystems@servoreelers.com

Tel: (718) 464-9400 Fax: 464-9435



MS-2

Two Servoreeler - remote control plate

The front plate of the MS-2 has an Incremental-Auto selector switch and two Up and Down pushbutton stations. The LED's indicate actual Servoreeler mode and operation.

DB-50 SRC output connector to DB-15 remote wall plate control.

<u>DB-50 pin number</u>	<u>Function _____</u>	<u>DB-15 pin number</u>
21	Master A Up	1
22	Master B Up	2
46	Master A Down	3
47	Master B Down	4
19	A Up led driver	5
20	B Up led driver	6
44	A Down led driver	7
45	B Down led driver	8
23	Auto mode enable	13
25	+24Vdc supply	14
50	Common	15

APPLICATION NOTES:

- 2- The LED indicator driver outputs provide a switched collector to common.

For any assistance, please call us at: 800: 431-8900

